

Henchman Trestle

User Manual

A Henchman Trestle Single has:







- 1 x Aluminium Platform
- 2 x Trestle Stands

A Henchman Trestle Double has:

- 2 x Aluminium Platforms
- 3 x Trestle Stands

Each Trestle Stand consists of:

- (a) 2 x A Frames
- (b) 1 x Cross Piece
- (c) 2 x Bracing Bars
- (d) 7 x 8 mm Bolts, Washers and Wing Nuts
- (e) 4 x Legs
- (f) 4 x L-Shaped Leg Handles and 4 x Shouldered Nuts



Henchman Trestle

User Manual

Assembly

1. Insert the shouldered nuts in the small brackets on the legs of the A Frames, with the shoulder facing outwards. Wind in the greased leg handles.
2. Insert the legs in the sleeves of the A Frames to the fullest extent, and tighten the handles.
ALWAYS KEEP THE HANDLE THREADS AND NUTS WELL GREASED.
3. Bolt the crosspiece to the tops of the A Frames, using the 8 mm bolts, washers and wing nuts.
4. Attach the bracing bars to the underneath of the crosspiece, and the other ends to the lugs on the A Frames – again using the 8 mm wing nuts.
5. Make sure the whole trestle stand is rigid by tightening the bolts.